



FRED SHEARER & SONS, INC.
ESTABLISHED 1916

Job Hazard Analysis		JHA # 15
Job/Task Title: Veneer Plaster Applications		
Safe Job Procedure:		Revised 11/2024
<p>This JHA is for the safe and successful completion of veneer plaster application. Special emphasis is placed on scaffold safety, protection from inhalation hazards, and eliminating strains and strains.</p>		
WORKERS MUST READ AND UNDERSTAND JHA #0 BEFORE BEGINNING ANY TASK		
<p>Review JHA's: #10 Lathing, #22 Baker Scaffolds, #23 Powered Tools and Equipment, #24 MEWP and Aerial Lift, #28 Scaffolding, #30 Covering and Cleanup, #34 Overhead Work</p>		
Step #1 Veneer Plaster Application		
Steps to Complete Job	Hazards	Preventive Measures
Mixing Plaster Materials.	Worker will be exposed to possible respiratory hazards, strains, sprains, and pinch points.	1) Additional PPE: Respirator or N95 dust mask while mixing and handling materials.
		2) Set up mixing area to minimize bending, twisting, lifting and moving of materials.
		3) Verify that electrical power is GFCI protected, cords are inspected, and assured grounding program is current. See assured grounding program at www.fsstools.com
		4) Use two hands on the drill motor.
Applying plaster material to wall or overhead.	Worker will be exposed to possible chemical hazards, falls, strains, and cuts.	1) Additional PPE: Wearing long sleeves is highly recommended for arm protection.
		2) Inspect area for possible trip and fall hazards. Remove or mark hazards accordingly.
		3) Any scaffold used for overhead work must have a solid deck when feasible.
		4) Store hand tools in such a way to minimize cut potentials.
		5) Use material carts to transport materials over long distances.
		6) Set up work for the work to avoid overreaching, twisting, and bending over.
		7) Keep work area clear of debris and excessive materials.

[Click Here to Sign](#)