



FRED SHEARER & SONS, INC.
ESTABLISHED 1916

Job Hazard Analysis		JHA # 37
Job/Task Title: Drywall Texture Application		
Safe Job Procedure:		Revised 11/2024
This JHA is for the safe and successful application of Stucco, either by hand or spray applied. Special emphasis is placed on eliminating strains, sprains, scaffold and MEWP safety, and respiratory policies.		
WORKERS MUST READ AND UNDERSTAND JHA #0 BEFORE BEGINNING ANY TASK		
Review JHA's #22 Baker Scaffolds, #23 Powered Tools and Equipment, #24 MEWP, #28 Scaffolding, #30 Cover and Clean-up, #34 Working Overhead		
Step # 1 Setting up Mixing Area and Compressor		
Steps to Complete Job	Hazards	Preventive Measures
Setting up material receiving area and setting up the compressor and lines.	Worker will be exposed to strains, sprains, pinch, slip, trip, loud noises, and fall hazards.	1) Organize material receiving area to accommodate incoming material.
		2) Secure material laydown.
		3) Secure stored materials against possible weather damage.
		4) Inspect all equipment for defects or worn parts at the start of each shift.
		5) Set-up mixing area and material to minimize lifting and twisting movements.
		6) Route airlines to minimize trip hazards, also protect lines from abrading against adjacent surfaces.
		7) Set-up equipment in a well-ventilated area to help disperse dust.
		8) Set-up mixing operation in an area that has solid footing and can be continually cleaned of spillage.
		9) Restrict access to mixing area to FSS employees only.
		10) Operator must wear hearing protection, and either a half-face fitted respirator, or N95 mask.
Step #3 Spraying Stucco		
Steps to Complete Job	Hazards	Preventive Measures
Spray applying stucco.	Worker will be exposed to possible slips, trips, falls and high-pressure hoses.	1) All scaffolding must have a solid, level deck and guardrails must be installed
		2) Keep feet on scaffold deck at all times.
		3) Avoid overreaching.
		4) Inspect work area before each shift and break. Look for obstructions, penetrations, holes, and



FRED SHEARER & SONS, INC.

ESTABLISHED 1916

		leading-edge conditions. Ensure trip hazards are eliminated or clearly marked.
		5) Pump operator and sprayer must be in clear and constant contact while spraying operation is in progress.
		6) Operator must wear hearing protection, and a half-face fitted respirator.

[Click Here to Sign](#)